

## CAPACITOR CONTACTORS type CNKN 12 -CNKN 25


### Features

- In conformity with: IEC 60947-1, IEC 60947-4
- Switching of 3 phase capacitors
- Ambient temperature of 55 °C
- Available in other AC voltages on request

### Selection and ordering data

#### AC coil operation

AC-6b utilization category For switching three-phase capacitors			Auxiliary contacts		Type	Weights kg
Capacitor rating at operating voltage 50 Hz		I <sub>e</sub> (A) 400 V/50 Hz	NO	NC		
230 V kVAr	400 V kVAr					
6,7	12	18	1	0	<b>CNKN 12 10</b>	0.49
			0	1	<b>CNKN 12 01</b>	
8.5	15	22	1	0	<b>CNKN 15 10</b>	0.67
			0	1	<b>CNKN 15 01</b>	
11	20	28	1	0	<b>CNKN 20 10</b>	0.68
			0	1	<b>CNKN 20 01</b>	
14	25	35	1	0	<b>CNKN 25 10</b>	0.71
			0	1	<b>CNKN 25 01</b>	



These CNKN contactors are equipped with early-make contacts. This special type of contact has the purpose of connecting for a very brief interval, 2-3ms, during the contactor closing, resistors which limit the connecting current of the capacitors.

# CAPACITOR CONTACTORS type CNKM 30 -CNKM 60


## Features

- In conformity with: IEC 60947-1, IEC 60947-4
- Switching of 3 phase capacitors
- Ambient temperature of 55 °C
- Available in other AC voltages on request

## Selection and ordering data

### AC coil operation

AC-6b utilization category For switching three-phase capacitors Capacitor rating at operating voltage 50 Hz			le (A) 400 V/50 Hz	Auxiliary contacts	Type	Weights  kg
230 V kVAr	400 V kVAr					
20	30	44	0 0	<b>CNKM 30 00</b>	0.94	
25	40	58	0 0 2 2	<b>CNKM 40 00</b> <b>CNKM 40 22</b>	1.58	
29	50	72	0 0 2 2	<b>CNKM 50 00</b> <b>CNKM 50 22</b>	1.6	
34	60	87	2 2	<b>CNKM 60 22</b>	2.4	



These CNKM contactors are equipped with early-make contacts.

This special type of contact has the purpose of connecting for a very brief interval, 2-3ms, during the contactor closing, resistors which limit the connecting current of the capacitors. These resistors are then excluded when the closing operation is complete and the current capacity is conveyed to the main contacts. With this type of circuit, it is possible to obtain minor wear of all the components of the system especially fuses and capacitors ensuring a longer life and better reliability.

# TECHNICAL INFORMATION

## CAPACITOR CONTACTORS TYPE

### CNKN 12 - CNKN 25, CNKM 30 - CNKM 50


#### Special contactors for power factor correction capacitors

#### Main characteristics

These contactors are equipped with early - make contacts. This special type of contact has the purpose of connecting for a very brief interval, 2-3 ms, during the contactor closing, resistances which limit the connecting current of the capacitors. These resistances are then excluded when the closing operation is complete and the current capacity is conveyed to the main contacts.

Type designation		CNKN 12 10 CNKN 12 01	CNKN 15 10 CNKN 15 01	CNKN 20 10 CNKN 20 01	CNKN 25 10 CNKN 25 01	CNKM 30 00	CNKM 40 00 CNKM 40 22	CNKM 50 00 CNKM 50 22	CNKM 60 22	
Capacitor rating at 230V	kvar	6,7	8,5	11	14	20	25	29	34	
	<b>400V</b> kvar	<b>12</b>	<b>15</b>	<b>20</b>	<b>25</b>	<b>30</b>	<b>40</b>	<b>50</b>	<b>60</b>	
Rated operational current Ie/AC6b et 400 V	A	<b>18</b>	<b>22</b>	<b>28</b>	<b>35</b>	<b>44</b>	<b>58</b>	<b>72</b>	<b>87</b>	
Insulation rating	V	690				750			1000	
Permissible ambient temperature	°C	- 25 to + 55								
Coil voltage tolerances		0,85 - 1,1 Un								
Maximum permissible fuse ratings	main circuit gL/gG	A	25	35	40	50	63	80	125	160
	auxilliary circuit	A	16	16	16	16	16	16	16	16
Frequency of switching operations	s/h	240	120	120	120	100	100	100	100	
Electrical endurance	x10 <sup>6</sup>	0,1								
Sizes of connecting conductors										
main circuit										
multi-wire conductor	mm <sup>2</sup>	2,5-4	6-25	6-25	6-25	6-25	16-35	16-35		
multi-wire cond. with cable shoe									50/8	

#### CONNECTION DIAGRAMS AND TERMINAL MARKINGS



CNKN 12 10, CNKN 15 10  
CNKN 20 10, CNKN 25 10

CNKM 30 00, CNKM 40 00  
CNKM 50 00

CNKM 40 22, CNKM 50 22

CNKM 60 22

**VERY IMPORTANT NOTE:**

For single compensation air coils or 3 - phase reactors (coils with magnetic core and air gap) are not necessary.

When the contactor is used for group compensation it's recommendable to use appropriate 3-phase filter circuit reactors (coils with magnetic core and air gap). This will reduce the value of higher harmonics and will prevent resonant current to prevail.

At single compensation the power of selected contactor is according to capacitor rated power.

At group and central compensation, when reactors are not in use, one step higher rating of the contactor is recommendable.


1




**Before switch the contactor in the circuit, capacitor must be discharged (the voltage at the terminals must be < 50 V).**

**During explotation, current value must not exceed the declared values.**

**CONECTION DIAGRAM FOR GROUP (CENTRAL) COMPENSATION**



**ORDER FOR CAPACITOR CONTACTORS**



**Example:** Capacitor contactor type CNKM 50 with two NO and two NC auxiliary contacts, control voltage 220 V, 50 Hz

**CNKM 50 22 220 V 50 Hz.**