www.sew.com.tw



# LCD Phase Sequence Indicator(Contact Type)



The 887 PR is a 3 Phases Presence and Rotation

Indicator.

It does not need any battery as it derives its power from the system under test.

It can be utilized on a 3 Phases Powered System without having to worry about damage to the tester or the system.

Once connected to a 3 phase power system, it indicates the phase presence by showing its corresponding LCD symbol.

It displays the rotation (clockwise or anti-clockwise) on


This instrument represents the guickest and easiest way for verifying the presence and rotation of a 3 phase system.

You can, before connecting Supply to Load, and from the supply side; Quickly and easily verify the presence of the three Phases on a 3 Phase Power System.

Confirm the Phase Rotation on a Powered 3 Phase System.

3 Phase Presence Indication circuit: This circuit uses the LCD to indicate if a phase is

These LCD indicators will light up when the voltage across any two phases are more than 40Vac.



3 Phase sequence Rotation indicator circuit: This circuit has also a LCD indication This product does not require any battery as it takes its power from the circuit under test.

# **FEATURES**

- Indicates phase rotation.
- Indicates phase presence.
- No battery required.
- Phase rotation phase presence indicated on large liquid crystal display.
- Small, rugged enclosure.
- Color coded test leads.
- Phase presence indication from as low as 40Vac to as high as 500Vac.
- Fused
- Lightweight, robust and compact.
- EN 61010-1 CAT III 600V EN 61010-2-032

# **SPECIFICATIONS**

#### **ELECTRICAL**

#### **Determination of the Phase Presence**

Nominal Voltage for Phase Presence Indication (the voltage required for the LCD L<sub>1</sub>, L<sub>2</sub>, L<sub>3</sub> indicators to come

From 40Vac to 600Vac.

From 15Hz to 400Hz. Frequency range

# **Determination of the Phases Rotary Field Direction:**

Direction Indication by LCD Display(the voltage required to have the LCD Direction Arrows to indicates and the  $L_1 L_2 L_3$  or  $L_3 L_2 L_1$  indicators to

From 40 to 600Vac.

Frequency range From 15 Hz to 400Hz

#### Protection

Over load	700V(between all terminals)
Over voltage	Class III - 700V towards ground
Fuses	2 × 0.5A/600V, 5 × 20mm, HBC, 600V Fast Blow

#### General

Current consumention	Mary 2mm
Current consumption	Max. 3mA

# **MECHANICAL**

Dimensions	150(L) × 72(W) × 33.8(D)mm
Material	Poly carbonate / ABS
Weight (less soft pouch)	Approx. 158.5g
Display	LCD

# **ENVIRONMENTAL**

Operating temperature range 1°C to + 55°C not in full sun!!! -20°C to + 70°C Storage temperature







3 Phases Presence Rotating Right L1L2L3



L1 Missing totation Indication

L2 Missing No Rotation Indication

L3 Missing No Rotation Indication